

MAGNA1

Safety instructions and other important information



Intertek

3191277

Conforms to ANSI/UL Std. 778

Certified to CAN/CSA Standard C22.2 No. 108



**Installation and operating
instructions**

GRUNDFOS.COM/MANUAL-MAGNA1

be
think
innovate

GRUNDFOS

English (US) Safety instructions

Original safety instructions

These safety instructions give a quick overview of the safety precautions to be taken in connection with any work on this product.

Observe these safety instructions during handling, installation, operation, maintenance, service and repair of this product.

These safety instructions are a supplementary document, and all safety instructions will appear again in the relevant sections of the installation and operating instructions.

Keep these safety instructions at the installation site for future reference.

General information

Target group



Prior to installation, read this document and the instructions. Installation and operation must comply with local regulations and accepted codes of good practice.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

Lifting the product



Observe local regulations concerning limits for manual lifting or handling.



Do not lift the pump head by the control box, i.e. the red area of the pump.

Installing the product

CAUTION



Crushing of feet

Minor or moderate personal injury
- Do not drop the pump head when loosening the clamp.

CAUTION



Pressurized system

Minor or moderate personal injury
- Pay special attention to any escaping vapor when loosening the clamp.

Fit and tighten the screw holding the clamp to 6 ± 0.7 ft-lbs (8 ± 1 Nm). Do not apply more torque than specified even though water is dripping from the clamp. The condensation is most likely coming from the drain hole under the clamp.



Check the position of the clamp before you tighten the clamp. Incorrect position of the clamp will cause leakage from the pump and damage the hydraulic parts in the pump head.



Do not insulate the control box or cover the control panel.

Electrical connection

Carry out the electrical connection and protection according to local regulations.

Check that the supply voltage and frequency correspond to the values stated on the nameplate.

WARNING

Electric shock

Death or serious personal injury
- Before starting any work on the product, make sure that the power supply has been switched off. Lock the main disconnect switch to the Off position.
Type and requirements as specified in national, state, and local regulations.



WARNING**Electric shock**

Death or serious personal injury

- Connect the pump to an external main disconnect switch with a minimum contact gap of 1/8 inch (3 mm) in all poles.
- The ground terminal of the pump must be connected to ground. Use grounding or neutralization for protection against indirect contact.

**WARNING****Electric shock**

Death or serious personal injury

Use a suitable type of Ground Fault Circuit Interrupter (GFCI) capable of handling ground fault currents with DC content (pulsating DC).



- If the pump is connected to an electrical installation where a GFCI is used for additional protection, this GFCI must be able to trip when ground fault currents with DC content occur.

- If rigid conduit is to be used, the hub must be connected to the conduit system before it is connected to the terminal box of the pump.
- Make sure that the pump is connected to an external main disconnect switch.
- The pump requires no external motor protection. When switched on via the power supply, the pump starts pumping after approximately 5 seconds.

Supply voltage

MAGNA1 S:

1 x 115-230 V \pm 10 %, 50/60 Hz, PE.

MAGNA1 ML variants:

1 x 115 V \pm 10 %, 50/60 Hz, PE.

1 x 208-230 V \pm 10 %, 50/60 Hz, PE.

Check that the supply voltage and frequency correspond to the values stated on the nameplate.

The voltage tolerances are intended for mains-voltage variations. Do not use the voltage tolerances for running pumps at other voltages than those stated on the nameplate.

Connecting the power supply

Make sure that the fuse is dimensioned according to the nameplate and local legislation.



Connect all cables in accordance with local regulations.



Make sure that all cables are heat-resistant up to 167 °F (75 °C). Install all cables in accordance with the National Electrical Code, or in Canada, the Canadian Electrical Code, and state and local regulations.

Product introduction

Do not pump aggressive liquids.



Do not pump flammable, combustible or explosive liquids.

Type key

Code	Example	()	40	-80	(F)	(N)	216
	Type range MAGNA1						
D	Single-head pump Twin-head pump						
	Nominal diameter (DN) of suction and discharge ports [mm]						
	Maximum head [dm]						
	Pipe connection						
F	Flange						
	Pump housing material						
N	Cast iron Stainless steel						
	Port-to-port length [mm]						

Fault finding

CAUTION

Pressurized system

- Minor or moderate personal injury
- Before dismantling the pump, drain the system or close the isolating valve on either side of the pump. The pumped liquid may be scalding hot and under high pressure.



WARNING

Electric shock

- Death or serious personal injury
- Switch off the power supply for at least 3 minutes before you start any work on the product.
 - Lock the main disconnect switch to the Off position. Type and requirements as specified in national, state, and local regulations.



WARNING

Electric shock

- Death or serious personal injury
- Make sure that other pumps or sources do not force flow through the pump even if the pump is stopped.



If the power supply cable is damaged, it must be replaced by the manufacturer, the manufacturer's service partner or a similarly qualified person.



Technical data

Ambient temperature

32 to 104 °F (0 to +40 °C).

During transport: -40 to 158 °F (-40 to +70 °C).

Liquid temperature

Continuously: +14 to +230 °F (-10 to +110 °C).
Stainless-steel pumps in domestic hot-water systems:

In domestic hot-water systems, we recommend that you keep the liquid temperature below 149 °F (65 °C) to eliminate the risk of lime precipitation.

System pressure



The actual inlet pressure and the pump pressure against a closed valve must be lower than the maximum permissible system pressure.

The maximum permissible system pressure is stated on the pump nameplate:

PN 12: 175 psi (12 bar / 1.2 MPa).

Installing a communication interface module

WARNING

Electric shock

- Death or serious personal injury
- Make sure that other pumps or sources do not force flow through the pump even if the pump is stopped. This will cause the motor to act like a generator, resulting in voltage on the pump.



WARNING

Electric shock

- Death or serious personal injury
- Switch off the power supply for at least 3 minutes before you start any work on the product.
 - Lock the main disconnect switch to the Off position. Type and requirements as specified in national, state, and local regulations.



Disposing of the product

This product has been designed with focus on the disposal and recycling of materials. The following average disposal values apply to all variants of pumps:

85 % recycling

10 % incineration

5 % depositing.

Dispose of this product or parts of it in an environmentally sound way according to local regulations.

See also end-of-life information on www.grundfos.com/product-recycling.

GRUNDFOS Kansas City

17100 West 118th Terrace
Olathe, Kansas 66061
Phone: (913) 227-3400
Fax: (913) 227-3500

www.grundfos.us

GRUNDFOS Canada

2941 Brighton Road
Oakville, Ontario L6H 6C9 Canada
Phone: +1-905 829 9533
Telefax: +1-905 829 9512

www.grundfos.ca

GRUNDFOS México

Boulevard TLC No. 15
Parque Industrial Stiva Aeropuerto
C.P. 66600 Apodaca, N.L. México
Phone: 011-52-81-8144 4000
Fax: 011-52-81-8144 4010

www.grundfos.mx

L-MAG-TL-10

98385926 0319

ECM: 1255914

Trademarks displayed in this material, including but not limited to Grundfos, the Grundfos logo and "be think innovate" are registered trademarks owned by The Grundfos Group. All rights reserved. © 2019 Grundfos Holding A/S, all rights reserved.